



QUICK GUIDE

LA1 TO 10 LAND CONNECTION CABINET

1. Enter the 8-digit code you have been given on the display.




2. The door on the right must be openend.




3. Plug the plug into the selected socket.

Note: The socket is de-energised when the door is open.



4. The cable must be routed out of the cupboard from beneath the right-hand door.



5. Make sure the door is properly closed again

Note: The socket is now live

